


F-Series Premium Fibre Laser

Built for coding. Made for you.



Domino. Do more.



Dominos F-Series range High-quality codes for less

F-Series is the ultimate fibre laser for your production line, allowing you to reduce your total cost of ownership for coding and marking while achieving top code quality. This fibre laser is a Domino-developed, market-proven laser technology, which is versatile and optimised for a variety of industries. With the F-Series range, Domino offers the models **F2**30i CP, **F2**30i EP, **F5**20i and **F7**20i, so you can choose the optimal power class and wavelength for your coding needs.

Total **Cost of Ownership** A more cost-effective coding technology

When considering a Domino laser for your production chain you can rely on the costeffectiveness of the F-Series. The combination of extended lifetime, high production uptime, and low consumables consumption ensures a much lower total cost of ownership than other coding technologies.



Up to 3x longer lifetime

In the challenging environments of industrial production, some coding technologies can have a relatively short life of less than 6 years before needing replacement. Due to limited moving parts and precision engineering, Domino's F-Series laser coders have a life span of up to 12 years of production.



Improve uptime

Laser coding requires virtually no planned maintenance and is inherently more reliable than alternative coding technologies. F-Series lasers enable you to increase your manufacturing uptime significantly and helps minimise your repair costs.



Reduce consumables

F-Series lasers do not require chemicals, solvents, or acids. F-Series lasers have an extraction system, which will need an occasional filter change. Consumables and related operational costs are reduced. The difference is significant.

Pulse Selector technology A perfectly tuned laser for **top-quality codes**

F230i EP comes standard with Pulse Selector technology. It gives you the ability to choose between 40 waveforms, so your laser is tuned to perfection to your material. Precision tuning is key when marking many substrates, including dark plastics or multilayer flexible films

Specific material selection

Fibre lasers are powerful tools which can mark a wide range of substrates with ease. **F2**30i CP has two waveforms with a given peak power, pulse energy, and pulse repetition frequency. This means you will get high-quality coding results for a certain range of materials such as light plastics and some metals.


Extended material variety

F230i EP's Pulse Selector technology provides the ability to choose between 40 waveforms. This variety gives you greater control of the pulse conditions and therefore of how the laser is tuned to your material. You can achieve the best in terms of quality, productivity, and substrate protection for an extended variety of materials such as light and dark plastics, multilayer flexible films, and many kinds of metals.

Sample lab recommendation

Domino's sample lab will test and recommend the most suitable waveform for your various applications and substrates. To switch substrates, simply select the recommended option from your Pulse Selector library, eradicating any need for trial-and-error and reducing unnecessary product waste.

Pulse Selector technology in the F230i EP





Waveform 0 can be used for engraving which is ideal for metals



Waveform 2 creates a colour change which is ideal for foils

Electronics


For housings, switches, power supply units, circuit boards, and many more

It's a small world

Electromechanical parts are getting smaller. F-Series hypersharp laser spot allows you to create ultra-fine precision codes on small components. You can mark at 150µm character height or a 14x14 Data Matrix code that is 1.2mm², all in high resolution with A-grade readability. F-Series lasers can even code complex messages with logos and graphics on small surface areas.



F-Series marks your molded plastic housings in high quantities



Add traceability to your PCB boards with 2D Data Matrix barcodes



High legibility through sharp coding

F-Series lasers create sharp, clear codes with excellent legibility. With an F-Series laser, you can create permanent human- and machine-readable codes, which are ideal for products with long and complex supply chains.

Maintain product integrity

Highly precise beam control ensures that F-Series lasers mark only where they are needed, without affecting other surrounding material or components.

Sharp clear codes are achieved with a bleaching effect on dark plastics

Food

For a wide range of food applications, from flexible pouches and films for confectioners and fruit packers, to plastic pots and steel tins for dairy producers and food canners

Coding on flexible film



Durable top-class coding

Codes on food products need to be indelible and resistant to abrasion or smearing that can cause poor readability. Poorly coded products typically need to be scrapped, causing waste and production losses. By contrast, F-Series offers reliable coding with high-clarity, permanent codes that will last the full length of the product's lifetime. This means your line waste can be dramatically reduced and your equipment efficiency improved.

Respects material barriers

Perforation or damage of barrier properties can be a concern with some laser technologies, especially when coding delicate film packaging as the material can be easily penetrated. F-Series Pulse Selector technology provides the ability to select a waveform with a non-thermal effect. This means that your substrates' colour is photochemically faded and the barrier properties remain completely unaffected.

Coding on steel tins



Full traceability

Ensure traceability of baby formula packs and give consumers confidence in the authenticity of your product. F-Series enables you to mark machine-readable codes for individual product traceability. The codes are permanent and can be applied at high speeds on cans of all different sizes.

Coding on plastic containers For dairy producers

F-Series marks high-contrast and sleek laser codes directly onto plastic containers. Codes are produced by a photochemical colour change, which doesn't affect the container's barrier properties. Because laser coding is a chemical-free technology it is ideal for aseptic packaging in a sterile environment.



Pharma

For pharmaceutical products and medical devices such as asthma cans, insulin pens, ampoules, and many more



Get discreet, sleek codes on devices with frequent patient contact

Discreet codes

Patients are often in close contact with medical devices such as asthma inhalers. F-Series codes are sleek in design to ensure discreet placement of traceability information.



F-Series codes are permanent, even when in contact with hand sanitisers

IPA and alcohol resistant

Having indelible traceability on medical devices is crucial especially where the use of sanitisers and washes could cause codes to be removed. The laser code is permanent and withstands treatment with IPA and alcohol.

Ideal for sensitive environments

F-Series is ideal for sensitive environments, as it is a completely chemical-free technology.

Futureproof coding

Compared to other laser coders, the F-Series lens offers an exceptionally wide marking area. This means that you can code multiple products simultaneously, for fast throughput. The wide marking area also allows for the addition of more complex data, should regulations of coding requirements change.



Marking of clearly readable scale on plastic bottles



F-Series lasers mark even rounded surfaces

Industrial

For industrial parts and automotive applications such as pipes, saw blades, oil filters, breaking discs, sparking plugs, or license plates

Resistant to heat and moisture

Ink-based coded metal parts can have issues with adhesion and permanence, especially when exposed to heat or chemicals, leading to costly product waste. Our F-Series is ideal for permanently marking metal parts with clear crisp codes. Codes can be applied in high-temperatures and wet processing environments, or where a product may be exposed to these conditions during assembly and use.



You can generate dark codes without engraving the metal by using an annealing effect

Coding anti-counterfeit elements

F-Series can code highly complex data with ease to ensure you can always identify counterfeit products. For example licence plates, which are laminated with laser sensitive foils, can be coded with anti-counterfeit elements such as elaborate watermarks.



Anti-counterfeit elements are coded on reflective foils with F-Series



F-Series marks many kinds of metals including steel, aluminium, titanium and brass

Adding permanent traceability information

F-Series allows you to mark your parts directly to enable complete traceability. F-Series codes are permanent and indelible, so they will remain on the product throughout its lifetime. They are nearly impossible to remove, so you can be sure that only authentic products will be returned back to you in the event of a recall.



F-Series codes are permanent even when exposed to heat or chemicals

Tobacco

For tobacco pouches and e-vapour products

Your partner in coding

No other company can compare to Domino's successful coding deployments to the tobacco sector. Domino has sold over 2500 lasers to the tobacco industry, and assists with coding trillions of packs per annum. F-Series, like all our laser products, is a proprietary Domino technology that benefits from our extensive expertise and heritage.

Serialisation at high speeds

With F-Series you can use Codentify® or other serialisation data format to code your products while keeping your production line running at high speed. You can mark your tobacco packaging with high-quality machine-readable codes such as Data Matrix and other barcodes without sacrificing your productivity.



Perfect readable codes on tobacco pouches made from polypropylene

A tobacco solution that's right for you

The small scanhead on the F-Series makes integration into OEM equipment easy and straightforward. Choose from over 100 application parts specifically designed for existing OEM tobacco lines and ensure your F-Series integration is efficient, fast, and safe. Get advanced vision systems for code verification, product handling, conveyor systems, and reject control, and benefit from a full tobacco solution package from a single supplier.

Complex codes, easily coded

Over the years, code formats for tobacco products have increased in complexity, particularly with the addition of machine-readable codes. With F-Series these large code formats (often with over 50 characters) can easily be printed at both high quality and high speed. Your codes will have strong contrast, excellent readability, and will always be in the right spot.





A full coding solution

SafeGuard Protect your investment

An outstanding level of care, wherever you are. Our **SafeGuard** packages provide high-quality, on-site assistance, and augmented reality enabled remote guidance from our engineers. **SafeGuard** helps to ensure we can be with you when you need us most.

Domino Cloud Smart production

Gain operational insight by connecting your printer to Domino Cloud. Obtain production analytics dashboards and receive system error alerts. Domino Cloud provides you with the information you need to run your operations more efficiently.

R-Series Code inspection automated

Ensure every code that leaves your factory is present and correct, and free up operator time. With the R-Series, Domino's range of vision control systems, you can automate your code inspection to validate code presence, placement, and readability.

QuickDesign Control your coding

Minimise errors using Domino's *QuickDesign* software. Control your product codes from a central location and streamline product changeovers. *QuickDesign* uses standard communication protocols including EtherNet/IP and can be integrated into existing ERP systems.

Value







Automatic code inspection



Control software



Your **professional partner** in coding

How can we help you?

Tell us what your coding problem is, and we will help you solve it. Our teams of in-house scientists, working all over the world, are available to test your substrate and determine the best laser solution for your requirements. This can be conducted virtually if you are unable to meet with our experts in person.

Safe and custom-fit integration

Domino's bespoke engineering services and unique guarding designs ensure that your laser installation will be safe and straightforward.

Open and responsive consultation

Domino has a broad coding technology portfolio and always recommends the best technology option for the customer. Each technology has advantages and any organisation considering installing a coder will be guided by their trusted Domino consultant to identify the machine which is right for their specific packaging and coding needs.



Lise to general and solver and so	Selecta ^b le waveforms Laser wavelength Laser power (maximum average output)	F2 30i CP	F2 30i E	P	F5 20i CP	F7 20i CP
Liker opering file description 207 207 1007 507 707 Vision opering description 1007 10	Laser wavelength Laser power (maximum average output)			Pulse Selector		
Lare power frammer were power in were power in the provide in the power were power pow	Laser power (maximum average output)			1059-1065nm	1	
Internal along Water uppl 1:03:07000 Water uppl 1:03:070000 Water uppl 1:03:070000 Water uppl 1:03:0700000 Water uppl 1:03:07000000 Water uppl 1:03:07000000000000000000000000000000000		20W	20W			70W
Desi:::10/jWW Desi::20/jWW		Wavelend	th: 630-670nm		Wavelength: 630-670nm	Wavelength: 630-670m
Catego parameters Despect to ling speed Despect to ling speed Grading speed Laser optimised from 6th high-speed transitivity (add well provided from runk language, and uncode Constructions) Supporting transitivity (add well provided from runk language, and uncode Constructions) Constructions and Weight, Intergration Lashed weight 300-571 (308 400-590-500 (308-571 (308)		Pma	x=390µW		Pmax=390µW	Pmax=5mW
Carling is leaded Supports Tright sport a polytic port and used of an unable polytic		Class L	aser Product		Class I Laser Product	Class 3R Laser Produc
Tores indexes Lise robinsed forms frigh-good marker in lander form, multi-langes, and uncode. Code contents Supporting value data with the second base of D_Support (S). Support of the second base of D_Support (S). Support (S). Code contents Support (S). Control end weight Support (S). Control end (S). Support (S).				bish as 1 P	1	
Graphics and logan The protocoloum of the subsection o		Laser	optimised fonts for high-sr	nign speed applica beed marking incl.	ition.* standard fonts. multi-language	and unicode.
Cade context Supporting "secolality configuration data.	Graphics and logos		*.bm	p (monochrome).	*.plt. *.dxf	
Focal legitivolang field 16dmm1118/L18/mm. 300mm1225/229mm Demension and Wight, Integration Laterhead wight 500 H14/k45/mm Concoller wight 37.00 Concoller wight 37.00 Concoller wight 37.00 Develop wight 37.00 Environment Concoller wight 37.00 Environment Concoller wight 37.00 Concoller wight 37.00 Environment Concoller wight 340°C 530°C (pp. 4-30°C coptional with water cooling PMS are cooled. PMS coptional with water cooling PMS are cooled. PMS coptional co		Supporti	More than 60 ID bar c	odes and 2 Data 1	Matrix codes. Supporting GST	I timo format
Later had weight in the set of the		Suppor til	160mm/118x118mm,	250mm/187×187r	nm, 300mm/229x229mm	a time iormat.
Laterhad wighting Bit Hadd wighting How	Dimension and Weight, Integration					
Controller dimminol (LWMH) 430-471-508 405-480 (volt or reade with quoties 145 and 245	Laserhead dimension				nm	
Controller weight: 37.4ig 0.03 getter 0.03 getter <td></td> <td>430</td> <td>×471×308</td> <td>7kg</td> <td>405~430</td> <td>V540</td>		430	×471×308	7kg	405~430	V540
Control weight 37.6 gr 0.0000 million 1.0000 million 1.00000 million 1.000000 million 1.000000 million 1.0000000 million 1.0000000 million 1.0000000 million 1.0000000 million 1.000000000000000000000000000000000000		-100	1717500	405×430×68		
Fibre length 1.Teck sam had. 2.Tim. bending radius 72mm Experiment Fibre length Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration through windowscam head orientations. Prevention 1.Ped sam had. Chartomole integration or the sam had. Chartomole integration or through windowscam head orientations. Product gated descent head head from head. Windowscam head orientations. 1.Ped sam had. Chartomole integration or through yield (Prevention Prevention Prevention Preventin Prevention Prevention Preventin Prevention Prevent	Controller weight	3	17.6kg		40.5kg	43kg
Integration 1 Feeds such head. Clustomiable integration through various such head orientations. Environment Operating Integration controller Prover computements 5 - 40°C 1.35°C (up to 45°C captional with water cooling IPS3 Integration controller Prover computements Prover computements 19-3 (air coded) IIPS3 air coded (PK5 optional with water cooling IPS3 INFS protection laser head Prover computements IIPS3 air coded (PK5 optional with water cooling IPS3 INFS protection laser head Prover computements Vering software User interface and Software User interface and Software Device develops Carabital user interface WYSWYC entry, TackPred (optional) (D - 240)/AC, 50(0)FE massa. Product develops Software Carabital due interface WYSWYC entry, TackPred (optional) (D - 240)/AC, 50(0)FE massa. Product develops Software Carabital due interface WYSWYC entry, TackPred (optional) (D - 240)/AC, 50(0)FE magsa. Product develops Software optional due due to the software Product develops Product develops Software optional due due to the software product develops Product develops User port Nil NO shutter connecting cable kit (45m, 9h), INS integration due to the software option rack mounting kit. Itser stand, fame software) User port Nil NO shutter, connecting cable kit (45m, 9h), INS integration due to the software option rack mounting kit. Itser stand, fame software (D - 0) User port Nil NO shutter, connecting cable kit (45m, 9h), INS integration due to the software option rack mounting kit. Itser stand, fame software into Sy	Fibre length		n	7m -bending radiu		Water cooled: 51.5kg
Operating emperature 5 - 4°C 5 - 3°C (up to 4°C copional with water cooling interaction content in the interaction of the interface and software (up to 4°C copional with water cooling interaction content interface and software (up to 4°C copional with water cooling interaction content interface and software (up to 4°C copional with water cooling interaction copies is configurated in our 2 and water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface and software (up to 4°C copional with water cooling interface water content interface WYSWYG entry. SuchArnel (up to 4°C copional with water cooling interface water content interface and software interacon software interface and software interfac		i-1				tations.
Operating emperature 5 - 40°C 5 - 30°C (up to 45°C optional with water cooling many protection taser hand ingress protection taser hand many protection taser hand many protection taser hand hower requirementoritier IPS 3 un cooled (IPS optional with water cooling Protection taser hand Protection taser Protection taser	Environment					
Ingress protection laser head 1P3 (air code) Prover requirements 1P3 (air cod	Operating temperature					optional with water cooling
Ingress protection controller Power requirements 101 - 200 WC 500 Hz 100 - 200 WC 500 Hz Dever requirements Cascholder Scholder 100 - 200 WC 500 Hz Dever requirements Cascholder Scholder 100 - 200 WC 500 Hz Dever requirements Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder 100 - 200 WC 500 Hz Marking software Cascholder Scholder Scholder 100 - 200 WC 500 Hz	Humidity		1		condensing	
Prover consumption max 3.5.4350/4 Constructions and Software User interface Constructions and Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language is configurable in our 25 Unsugges: During Software Control language: During Software Control language: During Software During Softwa		IP43	(air cooled)	162	IIP55 air cooled (IP65 opti	onal with water cooling)
<text><text><text><text><text><text><text><text></text></text></text></text></text></text></text></text>	Power requirements			100 - 240VAC,	50/60Hz	0,
Uter interface Chapbical user interface. WTS/WCRPharp, Yacuktkane (optional) Marking offware Charphical user interface. WTS/WCRPharp, Yacuktkane (optional) Private and Output Stand Output Signal input/outputs Staff incode/(difficient)) or islaw/ signal/signal/enge-ended signal) Signal input/outputs Staff incode/(difficient)) or islaw/ signal/enge-ended signal) Signal input/outputs Staff incode/(difficient)) or islaw/ signal/enge-ended signal) Signal input/outputs Staff incode/(difficient)) or islaw/ signal/enge-ended signal) Charles User port kit I/O, shuffer connocting cable kit (ASm Mi), Liser stand, fume extraction system Accessories Marking CE, cTÚVar / fulilis requirement: ROHS, FDA listed, EMC, PCC Staff incode/(difficient) Staff incode/(difficient)) Staff incode/(difficient) Staff incode/(d	Power consumption	max.	3.5A/350VA		max. 5.3A/	500VA
Uter interface Chapbical user interface. WTS/WCRPharp, Yacuktkane (optional) Marking offware Charphical user interface. WTS/WCRPharp, Yacuktkane (optional) Private and Output Stand Output Signal input/outputs Staff incode/(difficient)) or islaw/ signal/signal/enge-ended signal) Signal input/outputs Staff incode/(difficient)) or islaw/ signal/enge-ended signal) Signal input/outputs Staff incode/(difficient)) or islaw/ signal/enge-ended signal) Signal input/outputs Staff incode/(difficient)) or islaw/ signal/enge-ended signal) Charles User port kit I/O, shuffer connocting cable kit (ASm Mi), Liser stand, fume extraction system Accessories Marking CE, cTÚVar / fulilis requirement: ROHS, FDA listed, EMC, PCC Staff incode/(difficient) Staff incode/(difficient)) Staff incode/(difficient) Staff incode/(d	User Interface and Software					
Marking software QuidStep2 including Dynamad Integration Outputs, Interfaces Product detect imputs Product general software of (differential) or stated signal (ingle-ended) software valuable from corroller e.g. funce extractor, compressed airkit, water chiller encoder, or det hus, compris d. Interfaces Product detect Product detect det						
The stand Outputs, Interfaces NPN/PNP/24 sensor Product speed detect inputs Shaft encoder (differential) or steady signal (ingle-ended signal) Signal inputs/outputs Staft encoder (differential) or steady signal (ingle-ended signal) Nutriple inputs and outputs analable from controller eq. Nume extractor. compressed airkH, water chiller encoder: and coding done. Additional inputs available for oder ready compile of: and coding done. Additional inputs available for oder ready compile of: and coding done. Additional inputs available for oder ready (code bus; compile of: and coding done. Additional inputs available for oder ready (code bus; compile of: and coding done. Additional inputs available for oder ready (code bus; compile of: and coding done. Additional inputs available for oder ready. Super-Kett NUO. Super-Kett	Marking software					
Product speed detect inputs Spraduct speed detect inputs Accessories Correct and Accessories Correct and Correct and Correct and Accessories Correct and Correct and Correct and Correct and Correct and Correct and Accessories Correct and Correct	-		Quición	,		
Productive speed dreteed: Shaft encoder (differential) or staady signal (ongole-ended signal): Signal input/outputs Multiple inputs and interlocks. Output savailable for loss rand, coder busy, comple od, uncertaid, coder busy, comple od, uncertaid, coder busy, comple od, uncertaid, coder busy, comple od, uncertaid): Options and Accessories Deer port kit 100 shutter connecting cable kit (45.mg/m); USB image backup/restore kit, -Gour beach, neuroni, coder loss, comple od, uncertaid): Mere port kit 100 shutter connecting cable kit (45.mg/m); USB image backup/restore kit, -Gour beach, neuroni, coder loss, parama option rack mounting kit, laser stand, fune extraction system: Mere port kit 100 shutter connecting cable kit (45.mg/m); USB image backup/restore kit, -Gour beach, neuroni, neu					sansar	
Signal inputs/outputs Multiple inputs and outputs available from control of compressed air-kg, water chiller, encoder, sund coding done. Additional inputs available from control dos Curput signals provided for coder ready, coder busy, compile ox durations and coding done. Additional inputs available from control and programmable logic. USB, RS232. EherAtek (10/100 Moit, EherAtek) ¹⁰ (optional) Prions Water port kit I/O, shutter, connecting cable kit (4.5m, 9m), user port kit I/O, shutter, connecting cable kit (4.5m, 9m), colour baccon, heat exchange module (field compile cable). There is and, forme extraction system Accessories User port kit I/O, shutter, connecting cable kit (4.5m, 9m), colour baccon, heat exchange module (field compile cable). There is and, forme extraction system Application certification Marking CE, cTÚVus / Fulfills requirement: ROHS, FDA listed, EMC, FCC "Substrate, pitch and code dependent. Please consult your local sales agent" 14 Visuard (see additional inputs available from control of the dopendent please consult your local sales agent" 14 Visuard (see additional inputs available from control of the dopendent please consult your local sales agent" 14 Visuard (see additional inputs available from control of the dopendent please consult your local sales agent" 14 Visuard (see additional inputs available from control of the dopendent please consult your local sales agent" 14 Visuard (see additional inputs available from control of the dopendent please consult your local sales agent" 14						
Interaces Additional inputs there is define a start start coding control and programmable logs. USB, RS32, SterNext (U/U/OM Mbd), EtherNet(W/M) (2010). Accessories Was port kit I/O, shutter, connecting cable kit (45, m, m), USB image backup/restore kit, 4-colour bacao, velocity kit, accessories Was port kit I/O, shutter, connecting cable kit (45, m, m), USB image backup/restore kit, 4-colour bacaon, heat exchange module (PSO options chiller / factory water), pharma option rack mounting kit, laser stand. Ume exchange module Accessories Marking: CE, cTÜVus / Fulfills requirement: ROHS, FDA listed. EMC, FCC Startate, pitch and code dependent. Please consult your local sales agent Image backup/restore kit, 4-colour bacaon, velocity kit, laser startad. Ume exchange module Viburate, pitch and code dependent. Please consult your local sales agent Image backup/restore kit, 4-colour bacaon, velocity kit, laser startad. Ume exchange backup/restore kit, 4-colour bacaon, heat exchange backup/restore kit, 4-colour bacaon, heat exchange module Viburate, pitch and code dependent. Please consult your local sales agent Image backup/restore kit, 4-colour bacaon, velocity kit, laser start, long your local sales agent Image backup/restore kit, 4-colour bacaon, heat exchange backup/restore kit, 4-colour bacaon, heat exchange backup/restore kit, 4-colour backup/restore kit, 4-	Signal inputs/outputs					
Interfaces USB, RS232, EtherNet (10/100 Mbit), EtherNet/IPP* (optional) Options Wsb profit kit //O.shutter, connecting cable kit (45m, 9m, USB image backup/restore kit, 4-colour bacon, velocity kin, 4-colour bacon, heat exchange module (DPS options chiler / Attrice) watch, Pharma option Isser stand. fume extraction system Application certification Marking: CE, cTÜVus / Fulfills requirement: ROHS, FDA listed, EMC, FCC Fulfication certification Marking: CE, cTÜVus / Fulfills requirement: ROHS, FDA listed, EMC, FCC Fulfication certification Marking: CE, cTÜVus / Fulfills requirement: ROHS, FDA listed, EMC, FCC Fulfication certification Marking: CE, cTÜVus / Fulfills requirement: ROHS, FDA listed, EMC, FCC Fulfication certification Marking: CE, cTÜVus / Fulfills requirement: ROHS, FDA listed, EMC, FCC Fulfication certification Marking: CE, cTÜVus / Fulfills requirement: ROHS, FDA listed, EMC, FCC Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication Fulfication F						
Opions User port kit I/O, shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), Sm, Sm, Sm), Sm, Sm, Sm, Sm, Sm, Sm, Sm, Sm, Sm, Sm	Interfaces					
Opions User port kit I/O, shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), User port kit I/O, Shutter, connecting cable kit (Asm, Sm), Sm, Sm, Sm), Sm, Sm, Sm, Sm, Sm, Sm, Sm, Sm, Sm, Sm						
Accessories (PBS options chiller / factory water), pharma option lace stand, fume extraction system Appleation certification (PBS options chiller / factory water), pharma option lace stand, fume extraction system Appleation certification Marking: CE. cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC *Substrate, pitch and code dependent. Please consult your local sales are: Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image: CE cTUVus / Fufills requirement: ROHS, FDA listed, EMC, FCC Image:	Options					
Accessories and nume variable and the extraction system and the extrac				BIOCITY KIT,		
Subtrate, pitch and code dependent. Please consult your local sales are the formation of th	Accessories			rstem		
Subtrate, pitch and code dependent. Please consult your local sales arent to the formation of the formation						
Image: Constraint of the second se	Application certification		Marking: CE, cTÜVus / Fu	Ifills requirement: I	ROHS, FDA listed, EMC, FCC	
Image: Constraint of the constraint						
Etherica A Contraction of the co	Substrate, pitch and code dependent. Please consult your lo	ocal sales agent.	416			
Etherical Addition Systems A/S elundvej 46A & 46C. Herlev 56 47 10 73 00 ontakt@dominosystems.dk						
Etherica A Contraction of the co						~
Etherica A Contraction of the co						
Etherical Addition Systems A/S elundvej 46A & 46C. Herlev 56 47 10 73 00 ontakt@dominosystems.dk						
Etherical Addition Systems A/S elundvej 46A & 46C. Herlev 56 47 10 73 00 ontakt@dominosystems.dk						
VISIE AND INVISIE UNIT OF COMPANY INFORMATION INFORMAT	Ethow lot /IF					
VISIE AND INVISIE USE	EINEN/ei/iF				6.	
WISHE AND INVISIBLE LASER RADIATION RC0025-1203 MOD CYC OKXIC PDPSUE SX CONT Mod PYC OKXIC PD				560		
VISIBLE AND INVISIBLE USER RADIATION ICONSTRATIONING ICONSTRATIONI ICONSTRATIONI ICONSTRATIONI ICONSTRATIONI ICONSTRATIONI ICONSTR				(00)		
VISIBLE AND INVISIBLE LASER RADIATION ICORES-12014 AUDIC PT ON SUL DESCRIPTION SOUTHORN SOUT			-	680		
VISIBLE AND INVISIBLE USER AND INVISIBLE USER AND INVISIBLE USER AND INVISIBLE USER AND INVISIBLE SATTREED SATT						
VISIBLE AND INVISIBLE USER AND INVISIBLE USER AND INVISIBLE USER AND INVISIBLE USER AND INVISIBLE SATTREED SATT						471
tino Systems A/S elundvej 46A & 46C Herlev 5 47 10 73 00 ontakt@dominosystems.dk					430	
ino Systems A/S elundvej 46A & 46C Herlev 5 47 10 73 00 ontakt@dominosystems.dk						
ino Systems A/S elundvej 46A & 46C Herlev 5 47 10 73 00 ontakt@dominosystems.dk		≰ ∥				×/
elundvej 46A & 46C Herlev 5 47 10 73 00 ontakt@dominosystems.dk					1 (30
Herlev 5 47 10 73 00 ontakt@dominosystems.dk	AVOID EYE OR SUIN LASER RADDIATION RECORDS-1:2014 AVOID EYE OR SUIN EXPOSURE TO SOLTEERD RADDATION CLOSE 1-LASER PRODUCT					30
5 47 10 73 00 ontakt@dominosystems.dk	VISIBLE AND INVISIBLE LASER RADIATION ROORS-1 2014 TO Systems A/S					30
ontakt@dominosystems.dk	AND PY AND					30
465	AND EVER AND INVISIBLE LASER RADUATION ICCORES-12024 Manual And					30
	VISIBLE AND INVISIBE LASER RADIATION ICCORD-1-2004 AVDD C*C 04 Sett Dromet To Data To Data To Data To Data To Data To Data To Data To Data To Da			430		30
AVW_dominosystems_dk	VISIBLE AND INVISIBE LASER RADIATION ICCORD-1-2004 AVDD C*C 04 Sett Dromet To Data To Data To Data To Data To Data To Data To Data To Data To Da			130	499	30
	INTERE AND INVISION AND AND AND AND AND AND AND AND AND AND				499	30

F-Series-0321 UK Images may include optional extras or upgrades. Print quality may differ depending on consumables, printer, substrates and other factors. Images and photographs do not form any part of any terms and conditions between you and Domino.